


Kinetic Trolley – Operating Instructions:

Please Note: do not open or tamper with the electrics under the top deck, as this will void all warranty and or may cause serious injury to operators of the unit.

- 1) Check from the power indicator that the unit has sufficient charge and turn the unit on by pressing the red power button located on the side of the steering shaft located on the right hand side of the battery indicator.



To Operate the Unit:

- 2) To engage power supply, lower the handle so that it is almost in line with your waist, you should just be able to see the top of the handle console.




Forward / Reverse Operation:

- 3) To go backwards (tow) use your thumb to press the toggle down and to go forwards (push) use your thumb to press the toggle up.



Steering the Kinetic Trolley:

- 1) To steer, either pull the handle from left or right.



Buttons and Switches:

- 2) F.1 Shows the horn button located just above the red safety button for attracting attention. F.2. shows the FAST/SLOW speed switch to adjust the power of the unit to suit your environment and towing needs.

F1.



F2.



Emergency Stop:

- 3) For emergency stop press the big red safety button (See F3.). The switch is designed to engage if the operator makes firm contact with the unit whilst towing. Note: the black pads are not buttons (see F4.)

F3.



F4.



HEAD OFFICE & FACTORY
+61 3 9027 0800
+61 3 9027 0801
sales@liftmastermh.com.au
PO Box 125
Sunshine, VIC, 3020

NEW SOUTH WALES
1/14 Holbeche Rd
Arndell park NSW 2148
sales@liftmastermh.com.au
Ph: 02 9621 7594
Fax: 02 9676 6316

QUEENSLAND
453 Newman Rd
Geebung QLD
sales@liftmastermh.com.au
Ph: 07 3865 2756
Fax: 07 3865 2736

Faults:

Should you encounter any major concerns with your Kinetic Trolley please ensure you check the following items first:

1. Loss of drive - Ensure the battery is fully charged and or the Tiller handle has been placed back in the upright position which resets the unit.

From this try operating the unit and should this be succesful continue operation.

If not please contact your nearest Liftmaster Material Handling representative office for assistance.

HEAD OFFICE & FACTORY

+61 3 9027 0800
+61 3 9027 0801
sales@liftmastermh.com.au
PO Box 125
Sunshine, VIC, 3020

NEW SOUTH WALES

1/14 Holbeche Rd
Arndell park NSW 2148
sales@liftmastermh.com.au
Ph: 02 9621 7594
Fax: 02 9676 6316

QUEENSLAND

453 Newman Rd
Geebung QLD
sales@liftmastermh.com.au
Ph: 07 3865 2756
Fax: 07 3865 2736